

How to install or remove the Count Arthur Strong voice

Note: The voice will not work on the following devices: GO 40, GO 50, GO 60, GO 400, GO 500, GO 600, GO 5000, GO 6000, START 40, START 50, START 60.

How you install or remove voices depends on the program used by your device.

Devices using MyDrive

(For TomTom Home devices skip to that section below)



Before you start

Once you have bought the SatNav from the Count Arthur shop you will receive an e-mail from us which has the download links for the files that you need to install. A TomTom voice consists of 3 files, a .chk file, a .bmp file and a .vif file. Download these files and save them somewhere on your computer (hopefully remembering where you put them!)

Make sure that your computer is compatible with MyDrive Connect. (You should have done this before you bought the SatNav really but if you now find you can't install it let us know)

Make sure that you are using the latest version of MyDrive Connect.


You need to have software version 10.200 or higher installed on your navigation device to use this feature.

Adding Count Arthur's voice


Connect your navigation device to your computer. Switch on your device.

Click the icon (🌐 or 🌐) in the Windows notification area or Apple menu bar.

Click Manage community content.



A browser window opens:



Click Add voice.

Click Browse and go to where you saved your downloaded satnav files.

Select the voice files (data83.chk, data83.vif data83.bmp files) on your computer that you want to put on your device.

Note: If you have already installed other voice files on your satnav it is possible you will have used the same file number. If this is the case you can change the name of the files to, for instance, data84 or data85. The file names of the .chk, .vif and .bmp files must be identical.

Depending on your browser, you can select more than one file at the same time by holding down the Ctrl key (or Command key on a Mac) and selecting each of the files in turn.

Click Open. The webpage shows the selected voice.

Click Install.

The voice set is copied to your navigation device.

Removing Count Arthur's voice

Connect your navigation device to your computer. Switch on your device.

Click the icon (🔌 or 📶) in the Windows notification area or Apple menu bar.

Click Manage community content.

A browser window opens

Click **Remove** next to the voice you want to remove from your device. Make sure you remove the .chk, .vif and .bmp files for the voice you want to remove.

Devices using TomTom HOME

(For MyDrive devices see that section above)



Before you start

Once you have bought the SatNav from the Count Arthur shop you will receive an e-mail from us which has the download links for the files that you need to install. A TomTom voice consists of 3 files, a .chk file, a .bmp file and a .vif file. Download these files and save them somewhere on your computer (hopefully remembering where you put them!)

Adding Count Arthur's voice

1. Connect your device to your computer and launch TomTom HOME.
2. Click **Add Traffic, Voices, Safety Cameras etc.** in the main menu in HOME.
3. Click **Voices**.
4. Select to install a **Recorded voice**.
5. Select the voice you want to install.
6. Click **Add** to install one of the thousands of free voices that have been shared with the TomTom community.

Removing Count Arthur's voice

1. Connect your device to your computer and launch TomTom HOME.
2. Click **Manage my device** in the main menu in HOME.
Items are shown in groups.
To select one or two items in a group, click the plus sign to expand a group so you can see all the items in a group. Click the checkbox next to an item to select that item.
To select all the items in a group, select the checkbox alongside the group name.
3. Click the **Items on device** tab or the **Remove items from computer** tab.
4. Select individual items or groups of items by selecting the checkbox next to an item or group.
5. Click **Remove items**.

Disclaimer:

Before making any changes to your TomTom SatNav, it's always recommended that you back-up the data (which can be done with the supplied software).

When your SatNav is connected to a computer through a USB port always wait until any action you are running (copying the files, upgrading the application, installing the maps) is complete before disconnecting or switching off the TomTom.

Failure to do so may damage the data on the SD card or the Hard Drive.

Komedia Entertainment Ltd can accept no responsibility for any unintentional consequences resulting from the installation of our SatNav voices.